TABLE OF CONTENTS

VT-MX4430A

HITACHI

Video Deck

VHS

As an ENERGY STAR® Partner, our company has determined that this product meets the ENERGY STAR® guidelines for energy efficiency. ENERGY STAR® is a U.S. registered mark.

VT-MX4430A
Owner's Manual
Your Complete Guide
to Videocassette Viewing
and Recording

VCR Plus+

VCR Plus+ and PlusCode are registered trademarks of Gemstar Development Corporation.
The VCR Plus+ system is manufactured under license from Gemstar Development Corporation.

Using these quality features:

- Rotary 4-head Record/Playback System
- Bilingual on-screen menu display selectable in English or Spanish
- Infrared remote control
- Real time tape counter
- 181 channel capability PLL frequency synthesizer tuner with direct station call
- Auto power on and off system
- Auto counter reset
- Auto rewind when the end of a tape is reached
- Direct Button Operation
- 2 Step Picture Search Operation
- Still
- Digital Auto Tracking (DTR)
- Auto Repeat
- Rental Play Mode
- Three different tape speeds : SP/LP/SLP
- Two different recording tape speeds : SP/SLP
- IRT (Instant Recording Timer)
- 1 Year, 7 events (including Daily and Weekly Timer Recording)
- Timer Program Extension
- Auto Return
- Time Search
- Quick-Find
- Index Search
- Slow Motion
- The VCR Plus+ system

HITACHI HOME ELECTRONICS (AMERICA), INC.
1855 Dornoch Court,
San Diego, Ca 92173

Tel. 1-800-HITACHI
(1-800-448-2244)

HITACHI (HSC) CANADA INC.
6740 Campobello Road,
Mississauga, Ontario
L5N 2L8
Tel. 1-800-HITACHI
(1-800-448-2244)

QR31355 ©Hitachi, Ltd. 1999

Printed in China

TABLE OF CONTENTS

TABLE OF CONTENTS 2
IMPORTANT SAFEGUARDS 4
PRECAUTIONS 8
LOCATION 8
POWER SUPPLY 8
AVOID THE HAZARDS OF ELECTRICAL SHOCK AND FIRE 8
WARNING 8
FEATURES 10
VIDEO CASSETTE TAPE INFORMATION 12
PRECAUTIONS 12
TWO DIFFERENT TAPE SPEEDS 12
INSERTING A CASSETTE 12
REMOVING A CASSETTE 12
ERASE PREVENTION 13
OPERATING CONTROLS AND FUNCTIONS 14
PREPARATION FOR USE 17
ANTENNA/CABLE CONNECTIONS 17
RECORDING HINT 19
RECORDING HINTS 19
RECORDING HINTS 20
SETTING THE CH3/CH4 SWITCH 21
A/V TERMINALS 21
INSTALLING THE BATTERIES 22
SET UP FOR USE 23
CHANNEL SET UP (Automatic) 23
TO SELECT A DESIRED CHANNEL 24
CLOCK SET UP 25
TO CHANGE CLOCK SETTING 27
TO DELETE OR ADD CHANNELS 28
CHANNEL SET UP AGAIN 30
SELECTING THE LANGUAGE 30
NORMAL PLAYBACK 31
PICTURE SEARCH 31
STILL PICTURE 32
VERTICAL HOLD CONTROL 32
TRACKING ADJUSTMENT 32
SLOW MOTION 32
COUNTER MEMORY 32
TO EXIT THE COUNTER MEMORY 33
SPECIAL PLAYBACK 34
AUTO REPEAT PLAYBACK 34
TO EXIT THE AUTO REPEAT MODE 34
RENTAL PLAYBACK 35
TO EXIT THE RENTAL PLAY MODE 35
INDEX SEARCH 35
QUICK-FIND 37

TABLE OF CONTENTS

TO SKIP TO THE BEGINNING OF NEXT PROGRAM 37
TO VIEW AT NORMAL SPEED 37
TIME SEARCH 38
RECORDING 40
VIEWING AND RECORDING THE SAME PROGRAM 40
SKIPPING UNWANTED SCENES DURING RECORDING 41
RECORDING ONE PROGRAM AND VIEWING ANOTHER 41
TO MONITOR THE PROGRESS OF YOUR RECORDING 41
IRT (Instant Recording Timer) 42
TIMER RECORDING 44
AUTOMATIC TIMER RECORDING 44
HINTS FOR TIMER RECORDING 49
TIMER PROGRAM EXTENSION 49
TO CORRECT AN AUTOMATIC TIMER PROGRAM 49
TO STOP A STARTED AN AUTOMATIC TIMER PROGRAM 50
TO CANCEL OR CHECK THE START/END TIME 50
AUTO RETURN 50
WATCH THE RECORDED PROGRAM 51
SETTING THE GUIDE/USER CHANNELS FOR THE VCR PLUS+ SYSTEM 51
TO CHECK A PAIR OF CHANNEL NUMBERS 53
TO CORRECT A PAIR OF CHANNEL NUMBERS 54
TO CANCEL A PAIR OF CHANNEL NUMBERS 54
TIMER RECORDING USING THE VCR PLUS+ SYSTEM 55
COPYING A VIDEO TAPE 59
TO MONITOR THE RECORDING 59
ON SCREEN DISPLAY 61
DIGITAL DISPLAY 62
SPECIAL FEATURES 63
REAL TIME TAPE COUNTER 63
AUTO REWIND 63
TROUBLESHOOTING GUIDE 64
MAINTENANCE 65
SERVICING 65
CABINET CLEANING 65
HEAD CLEANING 65
TECHNICAL SPECIFICATIONS 66
CABLE CHANNEL DESIGNATIONS 67

WARNING!

TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK,
DO NOT REMOVE COVER (OR BACK).
NO USER-SERVICEABLE PARTS INSIDE.
REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

The caution marking is located on the rear of the cabinet.

This symbol indicates that dangerous voltage constituting a risk of electric shock is present within this unit.

This symbol indicates that there are important operating and maintenance instructions in the literature accompanying the appliance.

IMPORTANT SAFEGUARDS

1. Read instructions-All the safety and operating instructions should be read before the appliance is operated.
2. Retain Instructions-The safety and operating instructions should be retained for future reference.
3. Heed Warnings-All warnings on the appliance and in the operating instructions should be adhered to.
4. Follow Instructions-All operating and use instructions should be followed.
5. Cleaning-Unplug this video product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.
EXCEPTION: A product that is meant for uninterrupted service and, that for some specific reason, such as the possibility of the loss of an authorization code for a CATV converter, is not intended to be unplugged by the user for cleaning or any other purpose, may exclude the reference to unplugging the appliance in the cleaning description otherwise required in item 5.
6. Attachments-Do not use attachments not recommended by the video product manufacturer as they may cause hazards.
7. Water and Moisture-Do not use this video product near water, for example, near a bath tub, wash bowl, kitchen sink, or laundry tub, in a wet basement, or near a swimming pool, and the like.
8. Accessories-Do not place this video product on an unstable cart, stand, tripod, bracket, or table. The video product may fall, causing serious injury to a child or adult, and serious damage to the appliance. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer, or sold with the video product. Any mounting of the appliance should follow the manufacturer's instructions and should use a mounting accessory recommended by the manufacturer. An appliance and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the appliance and cart combination to overturn.

PORTABLE CART WARNING (Symbol provided by RETAC)

9.Ventilation- Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the video product and to protect it from overheating, and these openings must not be blocked or covered. The openings should never be blocked by placing the video product on a bed, sofa, rug, or other similar surface. This video product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to .

10.Power Sources-This video product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your appliance dealer or local power company. For products intended to operate from battery power, or other sources, refer to the operating instructions.

11. Grounding or Polarization- This video product is equipped with a polarized alternating current line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug.

12. Power Cord Protection- Power supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the appliance.

13. Outdoor Antenna Grounding-If an outside antenna or cable system is connected to the video product, be sure the antenna or cable system is grounded so as to provide some protection against voltage surges and built-up static charges. Article 810 of the National Electrical Code, ANSI/NFPA No. 70, provides information with regard to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna-discharge unit, connection to grounding electrodes, and requirements for the grounding electrode. (Fig. A)

Antenna ground diagram.

14. Lightning-For added protection for this video product during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the video product due to lightning and power-line surges.

15. Power Lines-An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits as contact with them might be fatal.

16. Overloading-Do not overload wall outlets and extension cords as this can result in a risk of fire or electric shock.

17. Object and Liquid Entry-Never push objects of any kind into this video product through any openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the video product.

18. Servicing-Do not attempt to service this video product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified

service personnel.

19. Damage Requiring Service-Unplug this video product from the wall outlet and refer servicing to qualified service personnel under the following conditions:
a. When the power-supply cord or plug is damaged.
b. If liquid has been spilled, or objects have fallen into the video product.
c. If the video product has been exposed to rain or water.
d. If the video product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the video product to its normal operation.
e. If the video product has been dropped or damaged in any way.
f. When the video product exhibits a distinct change in performance-this indicates a need for service.

20. Replacement Parts-When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock or other hazards.

21. Safety Check-Upon completion of any service or repairs to this video product, ask the service technician to perform safety checks to determine that the video product is in proper operating condition.

22. Heat-This video product should be situated away from heat sources such as radiators, heat registers, stoves, or other products (including amplifiers) that produce heat.

14. Lightning-For added protection for this video product during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the video product due to lightning and power-line surges.

15. Power Lines-An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits as contact with them might be fatal.

16. Overloading-Do not overload wall outlets and extension cords as this can result in a risk of fire or electric shock.

17. Object and Liquid Entry-Never push objects of any kind into this video product through any openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the video product.

18. Servicing-Do not attempt to service this video product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

19. Damage Requiring Service-Unplug this video product from the wall outlet and refer servicing to qualified service personnel under the following conditions:
a. When the power-supply cord or plug is damaged.
b. If liquid has been spilled, or objects have fallen into the video product.
c. If the video product has been exposed to rain or water.

d. If the video product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the video product to its normal operation.
e. If the video product has been dropped or damaged in any way.
f. When the video product exhibits a distinct change in performance-this indicates a need for service.

20. Replacement Parts-When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock or other hazards.

21. Safety Check-Upon completion of any service or repairs to this video product, ask the service technician to perform safety checks to determine that the video product is in proper operating condition.

22. Heat-This video product should be situated away from heat sources such as radiators, heat registers, stoves, or other products (including amplifiers) that produce heat.

PRECAUTIONS

LOCATION

For safe operation and satisfactory performance of your VCR, keep the following in mind when selecting a place for its installation:

• Shield it from direct sunlight and keep it away from sources of intense heat.
• Avoid dusty or humid places.
• Avoid places with insufficient ventilation for proper heat dissipation. Do not block the ventilation holes on the sides of the VCR.
• Install unit in a horizontal position.
• Avoid locations subject to strong vibration.
• Do not place the VCR near strong magnetic fields.
• Avoid moving VCR to locations where temperature differences are extreme.
• Do not place the VCR directly on top of the TV.

POWER SUPPLY

• AC 120V, 60Hz ONLY

AVOID THE HAZARDS OF ELECTRICAL SHOCK AND FIRE

• Do not handle the power cord with wet hands.
• Do not pull on the power cord when disconnecting it from AC wall outlet. Grasp it by the plug.
• If, by accident, water is spilled on your VCR, unplug the power cord immediately and take the unit to an Authorized Service Center for servicing.
• Do not put your fingers or objects into the VCR cassette holder.
• Do not place anything directly on top of the VCR.

WARNING

• Do not handle the power cord with wet hands.
• Do not pull on the power cord when disconnecting it from AC wall outlet. Grasp it by the plug.
• If, by accident, water is spilled on your VCR, unplug the power cord immediately and take the unit to an Authorized Service Center for servicing.
• Do not put your fingers or objects into the VCR cassette holder.
• Do not place anything directly on top of the VCR.Moisture condensation may occur inside the unit when it is moved from a cold place to a warm place, or after heating a cold room or under conditions of high humidity. Do not use the VCR at least for 2 hours until its inside is dry.

FCC WARNING- This equipment may generate or use radio frequency energy. Changes or modifications to this equipment may cause harmful interference unless the modifications are expressly approved in the instruction manual. The user could lose the authority to operate this equipment if an unauthorized change or modification is made.

IMPORTANT COPYRIGHT INFORMATION
Unauthorized recording or use of broadcast television programming, video tape, film or other copyrighted material may violate applicable copyright laws. We assume no responsibility for the unauthorized duplication, use or other acts which infringe upon the rights of copyright

owners.

WARNING: To prevent electric shock, match wide blade of plug to wide slot, fully insert plug.

The serial number of this product may be found on the back of the VCR. No others have the same serial number as yours. You should record the number and other vital information here and retain this book as a permanent record of your purchase to aid identification in case of theft. Serial numbers are not kept on file.

Date of Purchase	
Dealer Purchase from	
Dealer Address	
Dealer Phone No.	
Model No.	
Serial No.	

FEATURES

Rotary 4-head Record/Playback System- Rotary 4-heads to ensure excellent picture quality and special effects playback.
• **Bilingual on-screen menu display selectable in English or Spanish**
• **Infrared remote control**
• **Real time tape counter-** This shows the elapsed recording or playback time in hours, minutes, and seconds. (Does not work in blank areas of the tape)
• **181 channel capability PLL frequency synthesizer tuner with direct station call-** (A converter may be necessary to view scrambled cable channels.)
• **Auto power on and off system-** Automatically turns the VCR on as you insert the cassette, turns off after auto-rewind, and ejects when the beginning of the tape is reached.
• **Auto counter reset-** (Automatically resets tape counter "0:00:00" when a tape is inserted)
• **Auto rewind when the end of a tape is reached-** (Does not occur when using the timer recording).
• **Direct Button Operation-** When a tape is in the VCR and the power is off, just press PLAY, REW or F.FWD button on the main unit and it will automatically turn on the VCR and perform the desired function. (Does not occur when using the timer recording).
• **2 Step Picture Search Operation-** You can view a video program at a high speed or super high speed in either a forward or reverse direction . (Super high speed is available in LP and SLP mode only)
• **Still-** "Freeze" the picture at any time, for close viewing of a particular scene. Only tapes recorded in SLP mode will show a fairly clear picture.
• **Digital Auto Tracking (DTR)-** Automatically adjusts the tracking for each tape you play.
• **Auto Repeat-** Allows you to repeat a tape indefinitely without pressing the PLAY button.
• **Rental Play Mode-** Improves playback picture quality of worn tapes, especially rental tapes.
• **Three different tape speeds: SP/LP/SLP**
• **Two different recording tape speeds : SP/SLP**
• **IRT (Instant Recording Timer)-** Instant timed recording from 30 to 480 minutes possible at the push of the REC/IRT button.
• **1 Year, 7 events (including Daily and Weekly Timer Recording)-** The built-in timer allows you to record up to 7 programs at different times up to 1 year in advance. The daily timer allows recordings to be made of daily broadcasts, from Monday through Friday, and the weekly timer allows recording to be made once a week up to the end of the tape.
• **Timer Program Extension-** Allows you to shift the time schedule of a One Time Program for timer recording.
• **Auto Return-** After timer recording is finished, the VCR can return to the beginning of the recording automatically..
• **Time Search-** Lets you set the VCR to advance the tape by entering the desired playback time you want to skip.
• **Quick-Find-** Lets you search and confirm the contents of the recorded program(s) using the index mark.
• **Index Search-**Lets you Index the start of a recording.
• **Slow Motion-**You can view the video program at a slower than normal playback speed. Slow speed can be controlled by pressing the F.FWD button (faster) or the REW button (slower).
• **The VCR Plus+ system-** You can program the automatic timer recording using the PlusCode numbers that are printed in most newspaper TV listings and TV Guide magazine.

A NOTE ABOUT RECYCLING

This product's packaging materials are recyclable and can be reused. Please dispose of any materials in accordance with your local recycling regulations.

Batteries should never be thrown away or incinerated but disposed of in accordance with your local regulations
concerning chemical wastes.

VIDEO CASSETTE TAPE INFORMATION

This VCR will operate with any cassette that has the VHS mark. For best results, we recommend the use of high-quality tapes. Do not use poor quality or damaged tapes.






Tab
Plastic Tape

OPERATING CONTROLS AND FUNCTIONS

NOTE:

• We do not recommend the use f universal remote controls. Not all of the functions may be controlled with a universal remote control.

If you decide to use a universal remote control with this unit, please be aware that the code number given may not operate this unit. In this case, please call the manufacturer of the universal remote control.

-VCR FRONT PANEL



-REMOTE CONTROL



1. Cassette Compartment

2. REW button- Press to rewind the tape, or to view the picture rapidly in reverse during the playback mode. (Rewind Search)

◀ **button-** Press to cancel a setting of timer program. Press to correct digits when setting program (For example: setting clock or timer program). Press to add or delete channel numbers during channel preset. (only on the remote control)

3. STOP button- Press to stop the tape motion.

EJECT button- Press to remove a tape from the VCR.

▼ ▼ **button-** Press to enter digits when setting program (for example: setting clock or timer program). Press to select setting modes from on screen menu. (only on the remote control)

4. PLAY button- Press to begin playback.

▲ **button-** Press to enter digits when setting program (for example: setting clock or timer program). Press to select setting modes from on screen menu. (only on the remote control)

5. F.FWD button- Press to rapidly advance the tape, or view the picture rapidly in forward during playback. (Forward Search)

▶ **button-** When setting program (for example: setting clock or timer program), press to determine your selection and proceed to a next step you want to input. Press to determine setting modes from on screen menu. Press to add or delete channel numbers during channel preset. (only on the remote control)

6. Power button- Press to turn VCR on and off. Press to activate timer recording.

7. Remote sensor window- Receives the infrared signals from the remote control.

8. Digital display-See page 32.

9. CHANNEL(CH) ▲/▼ **buttons-**Press to select the desired channels for viewing or recording.
Tracking function-Press to minimize video 'noise' (lines or dots on screen) during playback (only on the VCR) or slow mode.
Press to stabilize the picture in the Sill mode when the picture begins to vibrate vertically.

10. REC button- Press for manual recording.
IRT button- Press to activates Instant Recording Timer. (only on the VCR)



11. NUMBER buttons- Press to select desired channels for viewing or recording. To select channels from 1 to 9, first press "0" button then 1 to 9. (only on the remote control)
+100 button- When selecting cable channels which are higher than 99, press this button first, then press the last two digits. (To select channel 125, first press "+100" button then press "2" and "5"). (only on the remote control)

12. MENU button- Press to display the menus on the TV screen. Press to exit the menus on the TV screen. (only on the remote control)

13. DISPLAY button- Press to display the counter or the current channel number and the current time on the TV screen. (only on the remote control)

14. TAPE SPEED button- Press to choose the desired recording speed : SP/SLP. (only on the remote control)

15. QUICK-FIND button- Quick Find mode. For more information, please read page 21. (only on the remote control)

16.TIME SEARCH button- Time Search mode. For more information, please read page 21. (only on the remote control)

17.INDEX SEARCH button- Index Search mode. For more information, please read page 21. (only on the remote control)

18. PAUSE button- Press to temporarily stop the tape during recording or to view a still picture during playback. (only on the remote control)
Frame Advance function- Press to advance the picture by one frame at a time during the still mode. (only on the remote control)

19. SLOW button- Press to start slow motion playback. The slow speed can be controlled by pressing the F.FWD button (faster) or the REW button (slower). (only on the remote control)

20. COUNTER MEMORY button- Press to set counter memory on and off. (only on the remote control)

21. COUNTER RESET button- Press to reset counter to 0:00:00. (only on the remote control)
EXIT button- Press to exit the menus on the TV screen. (only on the remote control)

22.VCR/TV button- Press to select TV or VCR mode. (only on the remote control)
VCR position: to view playback, to monitor video recordings or watch TV using the VCR tuner.
TV position: to watch TV or to view one program while recording another.

23. VCR Plus+ button- Press to program the automatic timer recording using the VCR Plus+ system. (only on the remote control)

24. Power cord- Connect to a standard AC outlet (120V/60Hz)

25. AUDIO OUT jack- Connect to the audio input jack of your audio equipment or another VCR

26. AUDIO IN jack- Connect to the audio output jack of your audio equipment or another VCR.

27. ANT. IN terminal- Connect to an antenna, Cable system or Satellite system.

28. VIDEO OUT jack- Connect to the video input jack of your video camera or another VCR.

29. VIDEO IN jack- Connect to the video output jack of your video camera or another VCR.

30. CH3/CH4 selector switch- Use to select a video output channel (3 or 4) for VCR playback.

31. ANT. OUT terminal- Connects to the antenna input terminal on your TV.

PREPARATION FOR USE

ANTENNA/CABLE CONNECTIONS

For some of the most common types of connections, please follow the drawings below. Use only one connection. For any further complex connections, please contact your local dealer or other qualified persons. (You may need additional accessories which are not supplied).

1 Disconnect the antenna or cable from your TV.	2 Connect the antenna or cable to the ANT. IN (Top jack) of your VCR.
3 Connect one end of the coaxial cable (supplied) to the ANT.OUT (Bottom jack) of your VCR.	4 Connect the other end of the coaxial cable (supplied) to the UHF/VHF antenna jack of your TV.

Fig.1: Indoor Antenna



You can record one channel while viewing another. The same goes for Automatic Timer Recording and IRT. For details, please refer to "Recording" on page 22.

Note: The connection of an indoor antenna with a VCR may not always give acceptable TV reception.

Fig. 2: VHF/UHF Combination Antenna or Cable fro the Cable Company


[Cable company]
[VHF/UHF combination antenna] (not supplied)
[Back of the VCR]
To VCR's ANT.IN (Top Jack)
[Back of the UHF/VHF combination TV] (New Style)
Matching transformer (not supplied)
Coaxial cable (supplied)
OR
[Back of the UHF/VHF separated TV] (Old Style)
UHF/VHF separator (not supplied)
To VCR's ANT.OUT (Bottom Jack)
Coaxial cable (supplied)

You can record one channel while viewing another. The same goes for Automatic Timer Recording and IRT. For details, please refer to "Recording" on page 22.

Continued on the next page.

Fig. 3: VHF/UHF Separate Antenna


[UHF antenna] (not supplied)
[VHF antenna] (not supplied)
[Back of the VCR]
To VCR's ANT.IN (Top Jack)
[Back of the UHF/VHF combination TV] (New Style)
UHF/VHF combiner (not supplied)
Coaxial cable (supplied)
OR
[Back of the UHF/VHF separated TV] (Old Style)
UHF/VHF separator (not supplied)
To VCR's ANT.OUT (Bottom Jack)
Coaxial cable (supplied)

You can record one channel while viewing another. The same goes for Automatic Timer Recording and IRT. For details, please refer to "Recording" on page 22.

Fig. 4: Cable Box and Satellite Box


[Cable Box or Satellite Box] (not supplied)
IN Jack
OUT Jack
[Back of the VCR]
To VCR's ANT.IN (Top Jack)
[Back of the UHF/VHF combination TV] (New Style)
Coaxial cable (supplied)
OR
[Back of the UHF/VHF separated TV] (Old Style)
UHF/VHF separator (not supplied)
To VCR's ANT.OUT (Bottom Jack)
Coaxial cable (supplied)

You can ONLY record and view the SAME channel when using this connection. There are no exceptions. The same goes for Automatic Timer Recording and IRT.

Note: Channel memory programming is NOT needed when using this connection.

RECORDING HINT

1) Be sure to check that the "PWR." and the "VCR" indicators are both on.
2) Turn on the TV and Box.
3) Set the channel to be recorded on the Cable Box.
4) Set the TV and VCR to channel 3 or 4.
5) Set the CH3/CH4 switch on the back of the VCR to match the channel set on the TV and VCR.
6) Press the REC button. For AUTOMATIC TIMER RECORDING, the VCR must stay on channel 3 or 4 at step [9] on page 25.

Continued on the next page.

Some customers with cable boxes may record one channel and view another, with either one of the connections below.

Satellite systems: Neither one of these connection will work. For satellite owner wishing to record one channel and view another, please contact the manufacture of the satellite system.

Fig. 5:


From the Cable Company
[2way signal splitter]
(not supplied)
coaxial cable (not supplied)
[Back of the Cable Box]
coaxial cable (not supplied)
coaxial cable (not supplied)
[Back of the VCR]
coaxial cable (not supplied)
[A / B switch] (not supplied)
coaxial cable (supplied)
On older TVs a matching transformer may be needed here. (not supplied)
[Back of the TV]

You can record a scrambled channel while viewing another.

RECORDING HINTS

1) Be sure to check that the "PWR." and the "VCR" indicators are both on.
2) Turn on the TV and Box.
3) Set the channel to be recorded on the Cable Box.
4) Set the TV and VCR to channel 3 or 4.
5) Set the CH3/CH4 switch on the back of the VCR to match the channel set on the TV and VCR.
6) Press the REC button. For AUTOMATIC TIMER RECORDING, the VCR must stay on channel 3 or 4 at step [9] on page 25.
7) Set the A-B switch to the other side. For AUTOMATIC TIMER RECORDING, set the A-B switch to the other side after step [12] on page 25.

8) Select the channel to be viewed on the TV.

Note: If you wish to see the VCR menu, view what you are recording or playing a tape with this connection, make sure the A-B switch is on the correct side.

Fig. 6:


From the Cable Company
CH3 CH4
ANT IN
OUT
[Back of the VCR]
coaxial cable (not supplied)
OUT IN
[Back of the Cable Box]
coaxial cable (supplied)
On older TVs a matching transformer may be needed here. (not supplied)
[Back of the TV]

This connection is good only if none of your channels are scrambled. You can record one channel while viewing another. Scrambled channels can not be recorded with this connection.

RECORDING HINTS

1) Be sure to check that the "PWR." and the "VCR" indicators are both on.
2) Turn on the TV and Box.
3) Set the channel to be recorded on the Cable Box.
4) Set the TV and VCR to channel 3 or 4.
5) Set the CH3/CH4 switch on the back of the VCR to match the channel set on the TV and VCR.
6) To view ONE channel while recording ANOTHER, the "VCR" indicator must bo off.
For AUTOMATIC TIMER RECORDING, the "VCR" indicator must be off after step [11] on page 25.
7) Set the channel to be viewed on the Cable Box.
8) Select the channel to be viewed on the TV.

Note: If you wish to see the VCR menu, view what you are recording or playing a tape with this connection, the "VCR" indicator must be on and the Cable Box channel must match the channel selected on the back of the VCR. (CH 3 or 4)

Note to CATV system installer
This reminder is provided to call the CATV system installer's attention to Article 820-40 of the NEC that provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of cable entry as practical.

SETTING THE CH3/CH4 SWITCH

If your TV does not have A/V terminals:
When the VCR is in the Playback mode or when the VCR is in the VCR position, your TV will receive signals from the VCR on either channel 3 or 4.
To use the VCR with your TV, set the selector switch to CH3 or CH4 (which is located in the back of your VCR), whichever is not used for normal broadcasts in your area. Then set your TV to the same channel.



A/V TERMINALS

CONNECTING TO INPUT JACKS

When you copy a video tape, or watch a program recorded on an another source, use the audio/video input jacks.

USING THE REAR JACK:

Fig. 7:



USING THE FRONT JACK:

You can use the audio and video input jacks on the front panel of the VCR instead of using the jacks on the back.

INPUT SELECT OF FRONT OR REAR

To use the audio/video input jacks, select the "L1" or "L2" position.
1) Be sure to check that the "PWR." and the "VCR" indicators are both on.
2) Turn on the TV and set the TV to channel 3 or 4. Now set the CH3/CH4 switch on the back of the VCR to match the channel selected on the TV.
3) Connect the audio/video cables to the audio/video input jacks on the back of the VCR. Now connect the other end of the cables to the audio/video output jacks on the source.
4)
• If you use the audio and video input jacks **on the back of the unit,** press 0, 0, 1 on the

remote control to select the "L1" position.
• If you use the audio and video input jacks **on the front of the unit,** press 0, 0, 2 on the remote control to select the "L2" position.
You may also select the "L1" or "L2" setting by pressing the CHANNEL(CH) or button.
Note: "L1" or "L2" is found before the lowest memorized channel. (Example: CH2)

CONNECTING TO OUTPUT JACKS

If your TV has A/V input jacks, you may connect your VCR's AUDIO/VIDEO OUTPUT jacks to the audio/video input jacks on back of your TV.

Direct audio/video connections usually result in a better picture and sound quality for tape playback. Please see your TV's owner's manual for A/V input connections.

Fig. 8:



INSTALLING THE BATTERIES

1) Open the battery compartment cover by pressing the cover on the remote unit in the direction of the arrow.
2) Insert 2 "AA" penlight batteries into the battery compartment in the direction indicated by the polarity (+/-) markings.
3) Replace the cover.



SET UP FOR USE

You can program the tuner to scan only the channels you receive in your area. You must use the remote control for this procedure.

NOTES:
• Channel memory programming is NOT needed when connected to a cable box or satellite box as in Fig 4 on page 11 or Fig 5 on page 12 In this case with your remote, select the VCR to channel 3 or 4 the same channel as located on the back of VCR (CH3 or CH4). Then the channel you wish to record or view may be selected on the cable box or satellite box.
• Follow me steps below only when you ping the VCR power cord into a standard AC outlet for the first time. If you unplug the VCR and move it to another area, follow "CHANNEL SET UP AGAIN" on page 16.
• You must follow the steps below before attempting to play or record a video tape. If you want to play or record a video tape BEFORE programming the tuner, you must first turn off the VCR. Then, press the POWER button again to turn it back on. To program the tuner again, see "CHANNEL SET UP AGAIN" on page 16.

CHANNEL SET UP (Automatic)

Plug in the VCR power cord
Plug the VCR power cord into a standard AC outlet. The "- - : - -" indicator flashes on the display.



Remember: If your cable box or satellite box is connected as in Fig 4 on page 11 or Fig 5 on page 12, you DO NOT have to set up the channels. Just select the TV and VCR to channel 3 or 4 and also have the CH3/CH4 switch on the back of the VCR to match the channel you selected (CH 3 or CH 4). Now select the Box to the channel you wish to view or record.

2 Select channel 3 or 4 on the TV
Turn on the TV and set the TV to channel 3 or 4. Now set the CH3/CH4 switch on the back of the VCR to match the channel selected on the TV.



[Back of the VCR]

3 Turn on the VCR
Press the POWER button to turn on the VCR. Both the "PWR." indicator and the "VCR" indicator on the VCR come on.

• Use the remote control for this procedure.

4 Select 'ENGLISH" or "ESPANOL"

Select "ENGLISH" or "ESPANOL"=Spanish by using the PLAY/ or STOP/ button. Then, press the MENU or F.FWD/ button.

NOTE: This function effects only the language on the screen menu and not the audio source.

LANGUAGE SELECT

ENGLISH [ON]
ESPANOL

5 Begin Channel preset

Press the F.FWD/ button once. The tuner scans and memorizes all active channels in your area.

• The VCR distinguishes between standard TV channels and cable channels.

CH 01

6 After scanning

The tuner stops on the lowest memorized channel. The TV screen returns to TV mode.

• If "TUNER SET UP'. appears on the TV screen again, check the cable connections. Press the MENU, F.FWD/ or REW/ button once again and the VCR will begin preset again.

CH 01

TO SELECT A DESIRED CHANNEL

You can select the desired channel by using the CHANNEL(CH) or button or directly pressing the number buttons on the remote control.

Note for using the number buttons:

• When selecting cable channels which are higher than 99, press the + 100 button first, then press the last two digits. (Example: to select channel 125, first press the +100 button then press "2" and "5").

• You must precede single-digit channel numbers with a zero (For example: 02, 03, 04 and so on).

CLOCK SET UP

Set the clock accurately for proper automatic timer recording. We suggest that you use a TV or radio station as your time source.

In the example below, the clock is to be set to:
DATE March 1st, 1999
SETTING TIME 5:40PM

• **Use the remote control for this procedure.**

• When in the Menu mode the following buttons only work (PLAY/, F.FWD/▶, REW/◀ STOP/▼ , RESET/EXIT, POWER and MENU).
• Be sure to check that the "PWR." and the "VCR" indicators are both on.
• Turn on the TV and set the TV to channel 3 or 4. Now set the CH3/CH4 switch on the back of the VCR to match the channel selected on the TV.



[Back of the VCR]

1 Select "SETTING CLOCK"

Press the MENU button. The SETTING CLOCK menu appears.

SETTING CLOCK

MONTH DAY YEAR

HOUR MINUTE AM/PM

-- : -- --

• The number buttons on the remote control do not work in this Menu mode.
• When you press the F.FWD/▶ button during steps [2] to [6], you may move forward to the next step.
• Press the REW/◀ button to go back one step from the current step during steps [3] to [7].

2 Select the month

Press the PLAY/ or STOP/▼ button repeatedly until the desired month appears. (Example: March - 03)

Then, the press F.FWD/▶ button.

SETTING THE CLOCK



3 Select the day

Press the PLAY/ or STOP/ button until the desired day appears. (Example: 1st □□ 01)
Then, press the F.FWD/ button.



4 Select the year

Press the PLAY/ or STOP/ button until the desired year appears.
(Example: 1999)
Then, press the F.FWD/ button.



5 Select the hour

Press the PLAY/ or STOP/ button repeatedly until your desired hour appears.
(Example: 05)
Then, press the F.FWD/ button.



HOUR MINUTE AM/PM

-- : -- --

6 Select the minute

Press the PLAY/ or STOP/ button repeatedly until your desired minute appears. (Example: 40)

Then, press the F.FWD/ button.

SETTING THE CLOCK

MONTH DAY YEAR
03/01 MON1999

HOUR MINUTE AM/PM

05 : --

7 Select "AM" or "PM"

Press the PLAY/ or STOP/ button to point to "AM" or "PM" (Example: PM)

SETTING THE CLOCK

MONTH DAY YEAR
03/01 MON1999

HOUR MINUTE AM/PM

05 : 40 AM
□PM

8 Start the clock

Press the RESET/EXIT or F.FWD/ button.
Although seconds are not displayed, they begin counting from 00 when you press the RESET/EXIT or F.FWD/ button. Use this feature to synchronize the clock with the correct time.

• When unplugging the AC-cord or if there is a power failure for more than 30 seconds, you may have to reset the clock.
• If the display shows an abnormal reading or no reading, unplug the power cord for more than 30 seconds. Then plug it back in. And reset clock.

TO CHANGE CLOCK SETTING

1) Press the MENU button until the INITIALIZE menu appears.
2) Press the PLAY/ or STOP/ button to point to "SETTING CLOCK". Then, press the F.FWD/ button.

3) Follow steps [2] to [8].

INITIALIZE

CHANNEL SET UP
SETTING CLOCK
LANGUAGE SELECT
GUIDE CHANNEL SET
GUIDE CHANNEL MAP

TO DELETE OR ADD CHANNELS

The channels you no longer receive or seldom watch can be deleted from the memory. (Of course, you can later add the deleted channel into the memory again.)

• Use the remote control for this procedure.

• Be sure to check that the "PWR." and the "VCR" indicators are both on.

· Turn on the TV and set the TV channel to 3 or 4. Now set the CH3/CH4 switch on the back



[Back of the VCR]

of the VCR to match the channel selected on the TV.

1 Select "INITIALIZE"

Press the MENU button on the remote control repeatedly so that the INITIALIZE menu appears.

INITIALIZE

CHANNEL SET UP
SETTING CLOCK
LANGUAGE SELECT
GUIDE CHANNEL SET
GUIDE CHANNEL MAP

2 Select "CHANNEL SET UP"

Confirm "CHANNEL SET UP" is pointed.

Then press the F.FWD/▶ button.

3 Select "ADD/DELETE CH"

Press the PLAY/▶ or STOP/▼ button repeatedly to point to "ADD/DELETE CH".

Then, press the F.FWD/▶ button.



4 Enter the desired channel number

Press the number buttons or the PLAY/▶ or STOP/▼ button until your desired channel number appears. (Example: CH02)



5 Delete it from memory

Press the F.FWD/▶ or REW/◀ button so that "DELETE" flashes on the TV screen.

• To delete another channel, repeat steps [4] and [5]

• If you press F.FWD/▶ or REW/◀ button again, the channel is memorized again.



- DELETED -



- MEMORIZED -

6 Exit the preset mode
Press MENU button on the remote control to return to TV mode.

NOTE: To confirm that channel(s) has been deleted or added, press the CHANNEL(CH) or ▼ button.

CHANNEL SET UP AGAIN

Remember: If your cable box or satellite box is connected as in Fig 4 on page 11 or Fig 5 on page 12, you DO NOT have to set up the channels. Just select the TV and VCR to channel 3 or 4 and also have theCH3/CH4 switch on the back of the VCR to match the channel you selected (CH 3 or CH 4). Now select the Box to the channel you wish to view or record.

• **Use the remote control for this procedure.**

1) Press the MENU button until the INITIALIZE menu appears.
2) Confirm "CHANNEL SET UP" is pointed to, then press the F.FWD/▶ button.
3) Confirm "AUTO TUNING" is pointed to, then press the F.FWD/▶ button. After scanning, the tuner stops at the lowest memorized channel.

• The VCR distinguishes between standard TV channels and cable channels.

CHANNEL SET UP

□AUTO TUNING
ADD/DELETE CH

SELECTING THE LANGUAGE

If you want to change the language on the TV screen, follow the steps below:
Note: This function effects only the language on the screen menu and not the audio source.

• **Use the remote control for this procedure.**
1) Press the MENU button on the remote control repeatedly so that the INITIALIZE menu appears.
2) Press the PLAY/ or STOP/▼ button to point to "LANGUAGE SELECT". Then, press the F.FWD/▶ button.
3) Select "ENGLISH" or "ESPANOL"= Spanish by using the PLAY/ or STOP/▼ button.
4) Press the RESET/EXIT button to return to TV mode.
NOTE: If for some reason the menu is in Spanish, press MENU button until "PARA INICIAR"

menu appears, press PLAY/ button to point to "SELEC.IDIOMA", press the F.FWD/ button, press the PLAY/ button to point to "ENGLISH", then press the RESET/EXIT button.

NORMAL PLAYBACK

[Back of the VCR]

PICTURE SEARCH

This feature is very useful in finding or skipping over a particular scene on a tape. In this mode, the sound will be muted.

1) You may view a video tape at a high speed in either a forward or reverse direction by pressing the F.FWD or REW button. (in the SP / LP / SLP modes)
2) Depress it again, the VCR will now search in super high speed. (in the LP / SLP modes only)

3) Press the PLAY button to return to normal speed.

STILL PICTURE

You can view a still picture on the TV screen during playback (the Still mode). Press the PAUSE button on the remote control during playback. Press the PLAY button to return to playback.
• You can advance the picture by one frame at a time by pressing the PAUSE button on the remote control during the still mode.
• If it is left in the Still mode for more than five minutes, the VCR will automatically switch to the Stop mode.

VERTICAL HOLD CONTROL

In the Pause/Still mode only, if the picture begins to vibrate vertically, stabilize the picture by pressing the CHANNEL(CH) or ▼ button.
NOTES:
• If the picture is distorted or rolling vertically, adjust the vertical hold control on your TV, if equipped.
• Most newer TV's do not have a user adjustable vertical hold control.

TRACKING ADJUSTMENT

• Tracking adjustment will be set automatically (Digital Tracking function) when you start playback.
However when playing pre-recorded tapes or tapes recorded on units other than your own, noise lines (black and white streaks) may appear on the playback picture. If this occurs, you can adjust the tracking control manually by pressing CHANNEL ▲ or ▼ button **on the VCR** until the streaks disappear.
To return to the DTR function, stop the tape once and start playback again.
• You can reduce the noise lines by pressing the CHANNEL(CH) ▲ or ▼ button is slow mode, too. Slow tracking adjustment will not be set automatically.
NOTE: In Still mode, press the SLOW button and press the CHANNEL(CH) ▲ or ▼ button until the streaks disappear. To return to Still mode, press the PAUSE button on the remote control again.

SLOW MOTION

Press the SLOW button to reduce the playback speed. The VCR mutes the sound during slow motion. You can control the speed by pressing the F.FWD button (faster) or the REW button (slower).

Press the PLAY button to return to normal playback.

NOTE: If it is left in the Slow mode for more than five minutes, the VCR will automatically go into the Stop mode.

COUNTER MEMORY

• Use the remote control for this procedure.
• Be sure to check that the "PWR." and the "VCR" indicators are both on.

• Turn on the TV and set the TV channel to 3 or 4. Now set the CH3/CH4 switch on the back of the VCR to match the channel selected on the TV.
• This feature only works with a prerecorded tape.

[Back of the VCR]

.

1 Stop tape at your desired point
Rewind or fast forward the tape to the beginning point at which you want to review.

2 Reset the counter to 0:00:00
Press the COUNTER RESET button on the remote. If necessary press the COUNTER RESET button again to reset the counter to 0:00:00.

3 Select the Counter Memory mode
Press the COUNTER MEMORY button on the remote control until "M" appears on the TV screen.

• The COUNTER MEMORY button does not function if the Auto Repeat mod is set ot [ON]. In this case, set the Auto repeat mode to [OFF].

M 0:00:00

4 Begin recording or playback
Press REC or PLAY button.
Press the STOP button when recording or playback is completed.

5 To activate the Counter Memory
Press the REW (or F.FWD) button, the VCR will stop automatically when the counter has returned to approximately 0:00:00. (approx.)
NOTE: The displayed time will not change during blank portions on the tape.

TO EXIT THE COUNTER MEMORY

Press COUNTER MEMORY button on the remote control so that "M" *disappears* from the TV screen.
On more information concerning the on screen display, please refer to page 32.

SPECIAL PLAYBACK

• **Use the remote control for the following procedure.**
• Be sure to check that the "PWR." and the "VCR" indicators are both on.
• Turn on the TV and set the TV channel to 3 or 4. Now set the CH3/CH4 switch on the back of the VCR to match the channel selected on the TV.

[Back of the VCR]

.

AUTO REPEAT PLAYBACK

The VCR has the auto repeat function that allows you to repeat a tape indefinitely without touching the PLAY button.
Make sure to insert a prerecorded tape.

1 Select "VCR SET UP"
Press MENU button until the VCR SET UP menu appears.

VCR SET UP

AUTO REPEAT
RENTAL
AUTO RETURN

2 Select "AUTO REPEAT"
Confirm "AUTO REPEAT" is pointed to.

3 Begin Auto repeat playback
Press the F.FWD/▶ button so that [ON] will appear next to "AUTO REPEAT" on the TV screen.

When in Stop mode, Repeat playback mode will start automatically.
· Once you select the Auto Repeat mode, it stays in effect even after you turn off the VCR.
· The COUNTER MEMORY does not function if the Auto Repeat mode is set to [ON]. In this case, set the Auto Repeat mode to [OFF].
· To stop playback, press the STOP button.

TO EXIT THE AUTO REPEAT MODE

Repeat steps [1] to [2], Then, press the F.FWD/▶ button. [ON] will then disappear from the menu. Press the RESET/EXIT button to return to TV mode

Power failure: If there is a power failure for more than 30 seconds, Auto Repeat Playback will go to off.

RENTAL PLAYBACK

This function enables you to improve the picture quality when playing back worn cassettes such as those rented from a video shop.
• **Selecting ON or OFF must be done during playback.**

1 Insert rental tape into VCR
Begin playback.

2 Select "VCR SET UP"
Press the MENU button on the remote control repeatedly so that the VCR SET UP menu appears.



3 Select "RENTAL"
Press the PLAY/ or STOP/ button repeatedly to point to "RENTAL".

4 Select "RENTAL" to [ON]
Press the F.FWD/ button so that "RENTAL ON" appears.

• Once you select the Rental mode, it stays in effect even after you turn off the VCR.
• To stop playback, press the STOP button.

TO EXIT THE RENTAL PLAY MODE

Repeat steps [1] to [3]. Then press the F.FWD/ button so that "RENTAL OFF" appears on the TV screen.

Power failure: If there is a power failure for more than 30 seconds, Rental Playback will go to off.

INDEX SEARCH

This feature provides a method of indexing the starting point so that it can be easily returned to in either fast forward or rewind mode.

· The index mark will be made automatically when the REC button is pressed. It will also be marked at the starting point of Timer recording, IRT.
· The index mark will not be recorded if the PAUSE button on the remote control is pressed and released during recording.
· The time gap between making the index marks on the tape should be greater than 1 minute

for SP recording, 2 minutes for LP recording and 3 minutes for SLP recording.
Example: You are watching program number 4 and want to fast forward to program number 7. You must skip three programs.



• You can choose the index search mode by pressing the INDEX SEARCH button on the remote control. Then continue with step [3].

1 Select "SEARCH SELECT"
Press the MENU button on the remote control repeatedly so that the SEARCH SELECT menu appears.

SEARCH SELECT

QUICK-FIND
INDEX SEARCH
TIME SEARCH

2 Select "INDEX SEARCH"
Press the PLAY/ or STOP/▼ button to point to "INDEX SEARCH". Then, press the F.FWD/▶ button.

3 Enter your desired number
Press the PLAY/ or STOP/▼ button until the number of programs that you want to skip appears.
(Example: "03" for 3 programs)

INDEX SEARCH

• The Index Search mode will be cancelled if the procedures are not activated in 30 seconds.

4 Begin Index Search
Press the REW or F.FWD button. The VCR begins rewinding or fast forwarding to the beginning of desired program.
NOTE: Every time an index signal is skipped, the number in the program indicator decreases by one.

5 After Index Search
When the preset program is reached, the VCR will start playback automatically.

• A video cassette must be inserted in the VCR for this function to work
• The number of Index Searches can be set up to 20.
• This function will not operate in the recording mode.
• When you want to cancel the Index Search while in progress, press the STOP button.

QUICK-FIND

This function enables you to search and confirm the contents of the recorded program(s) using the index mark.

The VCR begins fast forwarding by selecting this function. When the VCR find the beginning of the program (=the index mark), the VCR begins playback video tape at high speed for 30 seconds. Then, return to fast forwarding again to the beginning of next program. The VCR repeats these operation to the tape end.

Concerning the index mark, please see "INDEX SEARCH" section.
· Tape must be fully rewound.
· You can begin the Quick-Find by pressing the QUICK-FIND button on the remote control. You can also begin the Quick-Find by the following procedure.

1 Select "SEARCH SELECT"
Press the MENU button until the SEARCH SELECT menu appears.



2 Select "QUICK-FIND"
Confirm "QUICK-FIND" is pointed to, then press the F.FWD/▶ button. The VCR begins the Quick-Find.

TO SKIP TO THE BEGINNING OF NEXT PROGRAM

Press the QUICK-FIND button on the remote control.

TO VIEW AT NORMAL SPEED

Press the PLAY button. The Quick-Find is cancelled.
· A video cassette must be insert in the VCR for this function to work.
· This function will not operate in the recording mode.
· When you want to cancel the Quick-Find while in progress, press the STOP button.
· When the end of a tape is reached during the Quick-Find, the tape will automatically rewind to the beginning. After rewinding finishes, the VCR will eject the tape and turn itself to off.

TIME SEARCH

The Time Search function makes it possible to quickly advance the tape to your desired position simply by entering the exact amount of playback time you want to skip.

Example: To watch a program after 2 hours and 50 minutes from the present position, in either direction.

• You can choose the time search mode by pressing the TIME SEARCH button on the remote control. Then continue with step [3].

1 Select "SEARCH SELECT"
Press the MENU button until the SEARCH SELECT menu appears.

2 "TIME SEARCH"
Press the PLAY/ or STOP/▼ button to point to "TIME SEARCH". Then, press the F.FWD/▶ button.

3 Enter your desired time
Press the PLAY/ or STOP/▼ button until your desired time appears. ("2:50" stands for 2 hours 50 minutes)
• The Time Search mode will be cancelled if the procedures are not activated in 30 seconds.



4 Begin Time Search
By pressing the REW or F.FWD button, the VCR will rewind or fast forward to the specified point.
The time counts down as the searching progresses.

5 After Time Search
Playback starts automatically when 0:00 is reached.
• A video cassette must be inserted in the VCR for this function to work.
• Time Search can be set up to a maximum of 9 hours 59 minutes (9:59).

- This function will not operate in the recording mode.
- When you want to cancel the Time Search while in progress, press the STOP button.

RECORDING

· Please refer to the connection you are using, through pages 10, 11, or 12 on "ANTENNA/CABLE CONNECTIONS" before continuing.

• Be sure to check that the "PWR." and the "VCR" indicators are both on.

• Turn on the TV and set the TV channel to 3 or 4. Now set the CH3/CH4 switch on the back of the VCR to match the channel selected on the TV.



[Back of the VCR]

.

• Insert a cassette tape with its erase prevention tab in place. (If necessary, rewind or fast forward the tape to the point at which you want to begin recording.)

VIEWING AND RECORDING THE SAME PROGRAM

1 Select the channel to be recorded

Press the number buttons on the remote control or the CHANNEL (CH) ▼ or button.

CH 32

NOTE: If you have a cable box or satellite box connected to this VCR, please refer to "ANTENNA/CABLE CONNECTIONS" on pages 11 and 12 before proceeding to the next step.

2 Select the tape speed

Press the TAPE SPEED button on the remote control to select the desired tape speed (SP/SLP).

SP

3 Begin recording

Press the REC button. The "REC" indicator appears on the display.

REC

SP

NOTE: If any menu is activated on the TV screen, the REC button on the remote control does not function. Press the RESET/EXIT button to clear the menu. Then, press the REC button.

4 Stop recording
Press the STOP button when recording is completed.

SKIPPING UNWANTED SCENES DURING RECORDING

Press the PAUSE button on the remote control to temporarily stop recording.
Press the PAUSE or REC button to resume recording.

Press the PAUSE or REC button to resume recording.

PAUSE
□ □ □ □ □

NOTE: When the VCR is in the Pause mode, you may view the time remaining with □ marks on the TV screen. Each □ mark represents one minute. After five minutes, the VCR will automatically switch to the Stop mode to prevent tape damage. When there is 1 minute remaining, one □ will flash.

RECORDING ONE PROGRAM AND VIEWING ANOTHER

You can record one program while viewing another. To start recording, follow steps [1] to [3] under "VIEWING AND RECORDING THE SAME PROGRAM".
To select the channel you want to view at the TV, follow the steps below.

NOTE: If you have a cable box or satellite box connected to this VCR, please refer to "ANTENNA/CABLE CONNECTIONS" on pages 11 and 12 before proceeding to the next step.

4 Select the TV mode
Press the VCR/TV button on the remote control so that the "VCR" indicator on the VCR's digital display disappears

5 Select the channel on the TV
Set the TV to the channel you want to watch.

TO MONITOR THE PROGRESS OF YOUR RECORDING

1) Press the VCR/TV button on the remote control so that the "VCR" indicator on the display comes on.
2) Turn on the TV and set the TV channel to 3 or 4. Now set the CH3/CH4 switch on the back of the VCR to match the channel selected on the TV.

[Back of the VCR]

.

IRT (Instant Recording Timer)

This function enables you to set the recording length simply by pressing the REC/IRT button on the VCR.

• **Please refer to the connection you are using, through pages 10, 11, or 12 on "ANTENNA/CABLE CONNECTIONS" before continuing**.
• **You cannot use the remote control for this function.**
• Be sure to check that the "PWR." and the "VCR" indicators are both on.
• Turn on the TV and set the TV to channel 3 or 4. Now set the CH3/CH4 switch on the back of the VCR to match the channel selected on the TV.



[Back of the VCR]

• Insert a cassette tape with its erase prevention tab in place. (If necessary, rewind or fast forward the tape to the point at which you want to begin recording.)

PUSH(ES)	DISPLAY	RECORDED LENGTH
1 push	*(normal recording)*	
2 pushes	0:30	30 minutes
3 pushes	1:00	60 minutes
↓	↓	↓
17 pushes	8:00	480 minutes
18 pushes	*(normal recording)*	

NOTE: If you have a cable box or satellite box connected to this VCR, please refer to "ANTENNA/CABLE CONNECTIONS" on pages 11 and 12 before proceeding to the next step.

---

1 Select the channel to be recorded
Press the number buttons on the remote control or the CHANNEL(CH) ▼ or ▲ button.

2 Select the tape speed
Press the TAPE SPEED button on the remote control to select the desired tape speed (SP/SLP).

3 Begin IRT
Press the REC/IRT button on the VCR as many times as needed. The recording length will be determined by the number of times you press the REC/IRT button.
Each additional push will increase the recording time by 30 minutes. It can be set for up to 8 hours.

IRT (1:30)

• Recording starts immediately when the REC/IRT button is pressed, whether you are watching the same or a different channel.
• When the REC/IRT button is pressed 18 times, the VCR returns to the normal recording mode.
• To stop the IRT operation, press the STOP button on the VCR or on the remote control.
• To show the remaining time, press the DISPLAY button on the remote control so that "IRT" appears on the TV screen. (It will show up momentarily then disappear.)
• Recording stops when 0:00 is reached.
• Please note that in the SLP mode maximum recording time, assuming the tape is started at the beginning, is 8 hours using T-160 (or 6 hours using T-120).
• The TV that is connected to your VCR may be turned on or off during IRT.
• If the tape runs out before the end time, the VCR will switch to the Stop mode immediately, eject the tape and turn power off.

TIMER RECORDING

AUTOMATIC TIMER RECORDING

You may set the VCR to start and end a recording while you are away. You can set seven programs to record on specific days, daily or weekly within a 1 year period.

In the example below, the timer is being set to record:

DATE: May 6th, 1999
SETTING TIME: from 7:30PM to 8:30PM
CHANNEL: CH16
TAPE SPEED: SP
PROGRAM NO: No. 1

· Please refer to the connection you are using, through pages 10, 11, or 12 on "ANTENNA/CABLE CONNECTIONS" before continuing.

•Use the remote control for the following procedure.

• Be sure to check that the "PWR." and the "VCR" indicators are both on to program it.
• Turn on the TV and set the TV channel to 3 or 4. Now set the CH3/CH4 switch on the back of the VCR to match the channel selected on the TV.



[Back of the VCR]

.
· Clock must be set to the correct time and date before setting the timer.
· Insert a cassette tape with its erase prevention tab in place. (If necessary, rewind or fast forward the tape to the point at which you want to begin recording.)

Avoid overlap of programs ...

There is a case that a program will not be performed.
When programs overlap:
· The program with an earlier start time has priority.
· Once the earlier program finishes, the overlapping programs will begin recording in sequence.
· The illustration below demonstrates the sequence of recordings.



1 Select "TIMER PROGRAMMING"

Press the MENU button so that TIMER PROGRAMMING menu appears.



NOTE: If you have not yet set the clock, "SETTING CLOCK" appears. If so, follow the steps [2] to [8] on page 15. Then, set the timer recording.

2 Select your desired program number (1-7)

Program number which is not set up flashes.

Press the PLAY/ or STOP/ ▼ button until your desired program number appears. (Example: 1)

Then, press the F.FWD/▶ button.



3 Select once, daily, or weekly recording

For once recording:

Press the PLAY/ or STOP/ ▼ button to point to "ONCE", and then press the F.FWD/▶ button.



For daily recording: *To record a TV program at the same time on the same channel every day. (Example: Monday through Sunday)*

Press the PLAY/ or STOP/ ▼ button to point to "DAILY", and then press the F.FWD/▶ button.

PROGRAM NUMBER 1

ONCE
□ DAILY
WEEKLY

For weekly recording: *To record a TV program at the same time on the same channel every week. (Example: every Monday on ch 7 at 5:00PM)*

Press the PLAY/ or STOP/▼ button to point to "WEEKLY", and then press the F.FWD/▶ button.

PROGRAM NUMBER 1

ONCE
DAILY
□ WEEKLY

• When you press the F.FWD/▶ button during steps [4] to [10], you may move to the next step.
• Press the REW/◀ button to go back one step from the current step during steps [2] to [10].

4 Set the date when you want to start

First, press the PLAY/ or STOP/▼ button until the desired month appears. (Example: "05" for May)

Then, press the F.FWD/▶ button.

Next, press the PLAY/ or STOP/▼ button until the desired day appears, and then press the F.FWD/▶ button. (Example: "06" for 6th)

ONE TIME PROGRAM

PROGRAM NUMBER 1
DATE 05/ THUR
START TIME-- / -- --
END TIME -- / -- --
CHANNEL --
REC SPEED --

5 Set the start hour

Press the PLAY/ or STOP/▼ button until the desired hour appears. (Example: 07)

Then, press the F.FWD/▶ button.



6 Set the start minute

Press the PLAY/ or STOP/ button until the desired minute appears. (Example: 30) Then, press the F.FWD/ button.
Next, press the PLAY/ or STOP/ button to point to "AM" or "PM". (Example: PM) Then, press the F.FWD/ button.



7 Set the end hour

Press the PLAY/ or STOP/ button until the desired hour appears. (Example: 08) Then, press the F.FWD/ button.



8 Set the end minute

Press the PLAY/ or STOP/ button until the desired minute appears. (Example: 30) Then,

press the F.FWD/▶ button.
Next, press the PLAY/ or STOP/▼ button to point to "AM" or "PM". (Example: PM) Then, press the F.FWD/▶ button.

```
ONE TIME PROGRAM

PROGRAM NUMBER      1
DATE          05/06   THUR
START TIME07/ 30  PM
END TIME    08 / 30
CHANNEL     --
REC SPEED --
```

9 Set the channel number

Press the PLAY/ or STOP/▼ button until the desired channel number appears. (Example: 16) Then, press the F.FWD/▶ button.

• Remember refer to "ANTENNA/CABLE CONNECTIONS" on pages 11 and 12 if you have a cable box or satellite box before setting the channel number.

```
ONE TIME PROGRAM

PROGRAM NUMBER      1
DATE          05/06   THUR
START TIME07/ 30  PM
END TIME    08 / 30 PM
CHANNEL
REC SPEED --
```

10 Set the tape speed

Press the PLAY/ or STOP/▼ button until the desired tape speed appears. (Example: SP)

```
ONE TIME PROGRAM

PROGRAM NUMBER      1
DATE          05/06   THUR
START TIME07/ 30  PM
END TIME    08 / 30 PM
CHANNEL     16
REC SPEED
              □SP
               SLP
```

11 Finish setting the program

Press the F.FWD/▶ button. Program 1 is now completed.
• To set another program, repeat steps [2] to [11].
• Press the RESET/EXIT button to return to original mode.

12 Set the timer

Press the POWER button to turn off. The "☑" indicator appears on the VCR's digital display.
• Please see "HINTS FOR TIMER RECORDING" for more information.

HINTS FOR TIMER RECORDING

• If there is a power failure or the VCR is unplugged for more than 30 seconds, the clock setting and all timer settings will be lost.
• If the tape runs out before the end time, the VCR will switch to the Stop mode immediately, eject the tape and the VCR power will be turned off. The "☑" indicator will flash.
• If a tape is not inserted or the erase-protection tab is removed, the "☑" indicator flashes and timer recording cannot occur. Please inset a recordable tape.
• The TV that is connected to your VCR may be turned ON or OFF when the VCR is in the timer-record mode.

TIMER PROGRAM EXTENSION

To shift the time schedule of a One Time Program.
1) Turn the power on. Then, press the MENU button.
2) Select the program number which you want to shift forward using the PLAY/▶ or STOP/◀ button. The details of the selected program appears on the TV screen.
3) Press the REC button on the remote control when a program number is blinking. Each additional push will shift forward the start/end time for recording by 10 minutes. It can be shift forward for up to 24 hours.

When the recording is already in progress, each additional push will shift forward the end time for recording by 10 minutes. It can shift forward up to 23:50 from the start time. In this case, the recording speed will automatically be set to SLP mode.

If you want to cancel while the setting, press the PAUSE button on the remote control. The recording time returns to the original time.

4) Press the RESET/EXIT button to exit the setting menu.
NOTES:
• You can shift the time schedule of a One Time Program only.
• When you press the PAUSE button to cancel the setting while the recording is already in progress, the recording speed will stay in SLP mode.

TO CORRECT AN AUTOMATIC TIMER PROGRAM

1) Turn the power on.
2) Repeat steps [1] to [3] on page 24.
3) Go to the digit you want to change by using the F.FWD/▶ button or REW/◀ button.
4) Enter correct numbers using /PLAY or ▼/STOP button.
5) Press MENU button on the remote control to return to original mode.

6) Press POWER button to return to timer stand-by mode.

TO STOP A STARTED AN AUTOMATIC TIMER PROGRAM

Press STOP/EJECT button on the VCR.

NOTE: STOP button on the remote control will not function in the Automatic Timer Recording mode.

TO CANCEL OR CHECK THE START/END TIME

1) Turn the power on . Then press MENU button.
2) Select a program number you want to check using /PLAY or /STOP button. The details of selected program appears on the TV screen.
You may cancel the entire program by pressing REW/ button.
3) Press MENU button on the remote control to return to original mode.

AUTO RETURN

If you choose auto return to [AUTO] from the menu, when the timer recordings finish, the VCR will rewind to the beginning of the recorded programs.

***Make sure* ... If there are any remaining timer programs Once, Daily & Weekly, this function will not occur.**

1 Select VCR SET UP
Press the MENU button repeatedly so that the VCR SET UP menu appears.



2 Select "AUTO RETURN"
Press the PLAY/ or STOP/ button to point to AUTO RETURN".

3 Select "AUTO"
Press the F.FWD/ button so that [AUTO] appears next to "AUTO RETURN".



4 Exit the Auto Return mode
Press the RESET/EXIT button to return to original mode.

NOTE: To exit the auto return programming, repeat steps [1] to [2]. Then, press the F.FWD/▶ button. [AUTO] will then disappear from the menu. Press the RESET/EXIT button to return to TV mode.

WATCH THE RECORDED PROGRAM

Press the POWER button to turn on the VCR. Then, press the PLAY button.

SETTING THE GUIDE/USER CHANNELS FOR THE VCR PLUS+ SYSTEM

First, fill in the boxes below:
1) Write your local channel numbers **in "USER CH." column,** which you can receive in your area by channel preset.
2) Write local TV stations corresponding USER CH. **in "Call letters" column,** and write guide channel numbers corresponding call letters **in "GUIDE CH." column**, using see your TV guide magazine or the TV listings of your local newspaper.

Remember:
If your cable box or satellite box is connected as in Fig 4 on page 11 or Fig 5 on page 12, the local channel number (USER CH.) must be channel 3 or 4 for every a guide channel number (GUIDE CH.).

Channels Line-UP Chart		
Call letters (Local TV station)	GUIDE CH. (Guide channel number)	USER CH. (local channel number)

Now, compare the channel numbers you have written in the GUIDE CH. and USER CH. columns. You must set all of these channel numbers that don't match using the following procedure before you program the automatic timer recording using the VCR Plus+ system.
• This setting only needs to be set once, but must be done again if you use this VCR in another area by moving it.

1 Select "INITIALIZE"
Press MENU button until INITIALIZE menus appears.



2 Select "GUIDE CHANNEL SET"
Press /PLAY or ▼/STOP button to point to "GUIDE CHANNEL SET".
Then, press F.FWD/▶ button.

3 Enter a guide channel number (GUIDE CH.)
Press the number buttons or the PLAY/▲ or STOP/▼ button until a guide channel number you want to enter appears. (Example: 25)
Then, press the F.FWD/▶ button.
• You can select guide channels 01 - 99.

GUIDE CH
USER CH. --

4 Enter a user channel number (USER CH.)

Press the number buttons or the PLAY/▲ or STOP/▼ button until a user channel number you want to enter appears. (Example:50)

• You can select following user channels.
TV mode: channels 02 - 69 and L1 position*
CATV mode: channels 01 - 125 and L1 position*
[* To select line input for the user channel number (USER CH.), press 0, 0 on the remote control to select the L1 position.]

• Press the REW/◄ button to go back one step from current step.
• When selecting cable channels which are higher than 99, press the +100 button first, then press the last two digits using the number buttons.

GUIDE CHANNEL SET

GUIDE CH 25
USER CH.

5 Memorize a guide channel number and a user channel number you have selected

Press the MEMORY button.
• To set another, repeat steps [3] to [5].

6 Exit the guide channel set up mode

Press the RESET/EXIT button.

TO CHECK A PAIR OF CHANNEL NUMBERS

A list of all the GUIDE CH. numbers and corresponding USER CH. numbers memorized by the VCR is displayed on the TV screen.TO CORRECT A PAIR OF CHANNEL NUMBERS

1 Select "INITIALIZE"

Press MENU button until the INITIALIZE menu appears.

INITIALIZE

CHANNEL SET UP
SETTING CLOCK
LANGUAGE SELECT
GUIDE CHANNEL SET
□ GUIDE CHANNEL MAP

2 Select "GUIDE CHANNEL MAP"

Press /PLAY or /STOP button to point to "GUIDE CHANNEL MAP".

Then, press F.FWD/ button.

• If the channel you wish to check is not on the screen, press the F.FWD/ button to change the displayed page until you reach the correct page.

GUIDE CHANNEL MAP

GUIDE	USER GUIDE	USER
25 : 50	39	: 45
52 : 68	68	: 79
70 : 02	77	: 09
80 : 84		

3 To return to TV mode

Press the RESET/EXIT button

TO CORRECT A PAIR OF CHANNEL NUMBERS

1) Press MENU button until the INITIALIZE menu appears.
2) Press /PLAY or /STOP button repeatedly to point to "GUIDE CHANNEL SET". Then, press F.FWD/ button.
3) Enter the correct guide channel number using the number buttons or /PLAY or /STOP button.

Then, press F.FWD/ button.
4) Enter the correct user channel numbers using the number buttons or /PLAY or /STOP button.
Then, press MEMORY button.
5) Press RESET/EXIT button to return to original mode.

TO CANCEL A PAIR OF CHANNEL NUMBERS

1 Select "INITIALIZE"

Press MENU button until the INITIALIZE menu appears.

INITIALIZE

CHANNEL SET UP
SETTING CLOCK
LANGUAGE SELECT
GUIDE CHANNEL SET
□ GUIDE CHANNEL MAP

2 Select "GUIDE CHANNEL MAP"

Press /PLAY or /STOP button to point to "GUIDE CHANNEL MAP".

Then, press F.FWD/ button.

3 Select the channel you want to cancel.

Press /REW button. A pair of numbers flash.

Then, press /PLAY or /STOP button until the pair of numbers you want to cancel flash.

• If the channel you wish to cancel is not on the screen, press F.FWD/ button to change the displayed page until you reach the correct page.

GUIDE CHANNEL MAP

GUIDE	USER	GUIDE	USER
		39 :	45
52 :	68	68 :	79
70 :	02	77 :	09
80 :	84		

4 Delete it from memory

Press /REW button.

• If you want to cancel another channel, repeat steps [3] to [4].

5 To return to TV mode

Press RESET/EXIT button.

TIMER RECORDING USING THE VCR PLUS+ SYSTEM

You can program the timer using the PlusCode numbers that are printed in most newspaper TV listings and TV guide magazine. You can set seven programs including normal timer recording to record within one month. You need to coordinate guide channel numbers and user channel numbers before you program the automatic timer recording using the VCR Plus+ system. (Refer to "SETTING THE GUIDE/USER CHANNELS FOR THE VCR PLUS+ SYSTEM" on page 27.)

Make sure...

• You must use the remote control for this procedure.

• Be sure to check that the "PWR." and the "VCR" indicators are both on to program it.

• Turn on the TV and set the TV channel to 3 or 4. Now set the CH3/CH4 switch on the back of the VCR to match the channel selected on the TV.

• Clock must be set to the correct time and date before setting the timer.

• Insert a cassette tape with its erase prevention tab in place. (If necessary, rewind or fast forward the tape to the point at which you want to begin recording.)

1 Select the VCR Plus+ set up mode.
Press VCR PLUS+ button.

NOTE: If you have not yet set the clock, "SETTING CLOCK" appears. If so, follow the steps [2] to [8] on page 13. Then, set the timer.

2 Set the PlusCode number
Press the number buttons to set the PlusCode numbers of the program you want to record. Then, press VCR PLUS+ button.

NOTES:
• Press ◄/REW button to go back one digit from current digit while you set the code.
• If the code is not available, it will be cleared automatically when you press VCR PLUS+ button. Enter correct code and press VCR PLUS+ button again.
• If the code flashes when you press VCR PLUS+ button, this means that the number you entered was incorrect or the timer recording you just programmed and another timer recording overlapped.

3 Select once, daily or weekly recording
The timer recording program using the VCR Plus+ system is memorized to the lowest program number which is empty.

For once recording:
Press ►/PLAY or ▼/STOP button to point to "ONCE." Then, press F.FWD/► button.



For daily recording: *To record a TV program at the same time on the same channel from Monday through Friday,*
Press ►/PLAY or ▼/STOP button to point to "DAILY". Then, press F.FWD/► button.

WEEKLY

For weekly recording: *To record a TV program at the same time on the same channel every week. (Example: every Monday on channel 7 at 5:00 pm)*

Press /PLAY or ▼/STOP button to point to "WEEKLY". Then, press F.FWD/▶ button.

VCR PLUS+ PROG.

ONCE
DAILY
WEEKLY

4 Set the tape speed

Press /PLAY or ▼/STOP button until your desired tape speed appears.(Example: SP)

ONE TIME PROGRAM

PROGRAM NUMBER 1
DATE 05/06 THUR
START TIME07/ 30 PM
END TIME 08 / 30 PM
CHANNEL 16
REC SPEED
SP
SLP

5 Check that the program information is correct

• There are cases in which the program information does not match your area. If the incorrect information appears, select the number you want to change using the ◀/REW button. Then, enter the correct numbers using the /PLAY or ▼/STOP button.

Remember:

• If your cable box or satellite box is connected as in Fig 4 on page 11 or Fig 5 on page 12, the local channel number (USER CH.) Then, set your cable box or satellite box to the channel you want to record; leave your cable box or satellite box on for the timer recording.

6 Exit the VCR PLUS+ set up mode

Press MENU button.

To set another program, repeat steps [1] to [6].

7 Set the timer

Press POWER button. The "☑" indicator on the display comes on.

• Please see "HINTS FOR TIMER RECORDING" on page 25 for more notes.

COPYING A VIDEO TAPE

You can make copies of video tapes made by friends or relatives for your enjoyment.

Warning: Unauthorized recordings of copyrighted video tapes may be an infringement of copyright laws.

Connect the editing (recording) VCR, source (playing) VCR and your TV using the following diagram.

NOTE:
You can use the audio and video input jacks on the front panel of the editing (recording) VCR instead of using the jacks on the back.

Fig. 9:



1) Insert a pre-recorded video cassette into the source (playing) VCR.
2) Insert a blank video cassette, or one you want to record over, into the editing (recording) VCR cassette compartment.
3) Press the TAPE SPEED button on the remote control on the editing (recording) VCR to select the desired recording speed (SP/SLP) on the editing (recording) VCR.
4) Select the L1 or L2 position on the editing (recording) VCR. See page 13, under "Connecting to input jacks".
5) Press the REC button on the editing (recording) VCR.
6) Begin playback of the tape in the source (playing) VCR.

• For best results during dubbing, use the VCR's front panel controls whenever possible. The remote control might affect the playback VCR's operation.
• Always use video-quality shielded cables with RCA-type connectors. Standard audio cables are not recommended.
• You can use a video disc player, satellite receiver, or other audio/video component with A/V outputs in place of the playback VCR.
• If video or color fades in and out you may be copying a copy guarded video tape.

TO MONITOR THE RECORDING

1) • Turn on the TV and set the TV channel to 3 or 4. Now set the CH3/CH4 switch on the back of the VCR to match the channel selected on the TV.

[Back of the VCR]

.

2) Press the VCR/TV button on the remote control so that the "VCR" indicator on the display comes on.

ON SCREEN DISPLAY

NOTE: VCR power and the "VCR" indicator must be on.

• **To check the Count, Clock and Channel number,** press the DISPLAY button on the remote control. Each time you press the DISPLAY button on the remote control, TV screen will change as the illustration:



• It is normal for the status display (STOP, PLAY etc.) and the tape speed display (SP, LP, or SLP) to disappear after 5 seconds.

DIGITAL DISPLAY

1. PWR. (power) indicator- Lights up when the power is turned on.

2. ☑ indicator- Lights up when a timer recording or an **IRT** has been set. Flashes if a tape is not inserted in the VCR even if you set a timer.



• It is normal for the status display (STOP, PLAY etc.) and the tape speed display (SP, LP, or SLP) to disappear after 5 seconds.

1. PWR. (power) indicator- Lights up when the power is turned on.

2. ☑ indicator- Lights up when a timer recording or an IRT has been set. Flashes if a tape is not inserted in the VCR even if you set a timer.

3. Cassette indicator- Lights up when there is a tape in the VCR.

4. VCR indicator- Indicates that the VCR is in the VCR position.

5. REC indicator- Lights up when the VCR is in the Recording mode. Flashes when a recording has been paused.

6. Clock/Feature/Channel indicator- Indicates the current time (when the clock is set), and briefly displays which feature the VCR is currently performing as the illustration. Indicates the channel number (when it is set).



SPECIAL FEATURES

REAL TIME TAPE COUNTER

• This shows the elapsed recording or playback time in hours, minutes, and seconds. (The displayed time will not change during blank portions on the tape.)
• The "-" indication will appear when the tape is rewound further than "0:00:00" on the tape counter.

AUTO REWIND

When the end of a tape is reached during recording, playback, or fast-forward, the tape will automatically rewind to the beginning. After rewinding finishes, the VCR will eject the tape and turn itself to off.
• The tape will not auto-rewind during timer recording or Instant Recording Timer.
• When the Counter Memory is activated, the tape will rewind to the MO:00:00 and the VCR will go into the Stop mode.

TROUBLESHOOTING GUIDE

If you have followed the instructions contained in this manual and have difficulty in operating your VCR, locate the PROBLEM in the left column below. Check the corresponding CORRECTIVE ACTION columns to remedy the problem.

PROBLEM	CORRECTIVE ACTION
No power.	• Make sure the AC cord is connected to an AC outlet • Make sure the power is turned on.
Timer recording is not possible.	• Make sure the timer recording is set correctly. • Make sure the power is off. • Make sure the VCR clock is set correctly.
Cannot go into Record mode.	• Make sure the tape has an erase-prevention tab. If needed, cover the hole with plastic tape.
Playback picture is partially noisy	• Adjust tracking control for a better picture by using the CHANNEL ▲ or ▼ button on the VCR.
No picture but the audio is OK in playback.	• Head cleaning may be necessary. Refer to "HEAD CLEANING" on page 34.
No picture or poor picture on playback.	• Set your TV to the VCR mode and/or press the VCR/TV button on the remote control so that the "VCR" indicator on the display comes on. • Fine tune your TV.
On-the-air TV program cannot be seen.	• Re-check the ANT. IN and ANT.OUT connections. See page 10. • Set your TV to the TV mode and/or press the VCR/TV button on the remote control so that the "VCR" indicator on the display disappears..
No operation from the infrared Remote Control	• Make sure the AC cord is connected to an AC outlet. • Check batteries in remote control
Video or color fades in and out when making a copy of a video tape	• None. (You are copying a copyrighted tape and are experiencing copy guard protection.)

MAINTENANCE

SERVICING

Should your VCR become inoperative, do not try to correct the problem by yourself. There are no user-serviceable parts inside. Turn off, unplug the power cord, and take the unit to Hitachi Authorized Service Center for servicing.

CABINET CLEANING

• Wipe the front panel and other exterior surfaces of the VCR with a soft cloth immersed in lukewarm water and wrung dry.
• Never use a solvent or alcohol. Do not spray insecticide liquid near the VCR. Such chemicals may cause damage and discoloration to the exposed surfaces.

HEAD CLEANING

• Playback picture may become blurred or interrupted while the TV program reception is clear. Dirt accumulated on the video heads after long periods of use, or the usage of rental or worn tapes can cause this problem.
If a streaky or snowy picture appears during playback, the heads of your VCR may need to be cleaned.
1. Please visit your local Audio/Video store and purchase a good quality VHS Video Head Cleaner.
2. If a Video Head Cleaner does not solve the problem, consult the nearest Authorized Service Center. Professional video head cleaning requires highly technical attention.

NOTES:
• Remember to read the instructions included with the video head cleaner before use.
• Clean video heads only when problems occur.

TECHNICAL SPECIFICATIONS

Format:	VHS
Video Signal System:	NTSC color EIA standard
Record/Playback System:	Video: 4 heads
Tape Speed:	33.35mm/sec (SP), 16.67mm/sec (LP)(Playback Only), 11.12mm/sec (SLP)
RF Input:	UHF/VHF 75 ohm
Tuner:	181 channel tuning ability *(125 cable channels)
Type:	Auto programming frequency synthesis
Power Input:	AC120V 60Hz
Power Consumption:	16 W nominal
Cabinet Size:	14-1/4" (W) x 3-5/8" (H) x 9-1/16" (D) 36.0cm (W) x 9.2cm (H) x 23.0cm (D)
Weight:	5.51 lbs. (2.5 kg) (approx.)
Storage Temperature:	-4°F to 131°F
Operating Temperature:	41°F to 104°F
Accessories:	1 coaxial cable (Part No. 5857952), 1 remote control unit (Part No. HL11183), 2 AA batteries

* Check your cable company's compatibility requirements.

- **Design and specifications subject to change without notice.**
- **If there is a discrepancy between languages, the default language sill be English.**

CABLE CHANNEL DESIGNATIONS

If you subscribe to cable TV, the channels are displayed as 1-125.

Cable companies often designate channels with letters or letter-number combinations. Please check with your local cable company. The following is a chart of common cable channel designations.

CATV Channel	5A	2	3	4	5	6	7	8	9	10	11	12	13	A	B
VCR Display	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
CATV Channel	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q
VCR Display	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30
CATV Channel	R	S	T	U	V	W	W+1	W+2	W+3	W+4	W+5	W+6	W+7	W+8	W+9
VCR Display	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45
CATV Channel	W+10	W+11	W−12	W+13	W+14	W+15	W+16	W+17	W+18	W−19	W+20	W+21	W+22	W+23	W+24
VCR Display	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60
CATV Channel	W+25	W+26	W+27	W+28	W+29	W+30	W+31	W+32	W+33	W−34	W+35	W+36	W+37	W+38	W+39
VCR Display	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75
CATV Channel	W+40	W+41	W+42	W+43	W+44	W+45	W+46	W+47	W+48	W+49	W+50	W+5	W+52	W+53	W+54
VCR Display	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90
CATV Channel	W+55	W+56	W+57	W+58	A-5	A-4	A-3	A-2	A-1	W+59	W+60	W+61	W+62	W+63	W+64
VCR Display	91	92	93	94	95	96	97	98	99	100	101	102	103	104	105
CATV Channel	W+65	W+66	W+67	W+68	W+69	W+70	W+71	W+72	W+73	W+74	W+75	W+76	W+77	W+78	W+79
VCR Display	106	107	108	109	110	111	112	113	114	115	116	117	118	119	120
CATV Channel	W+80	W+81	W+82	W+83	W+84										
VCR Display	121	122	123	124	125										

DECLARATION OF CONFORMITY

_____with FCC Rules for Electromagnetic Compatibility

Products: Video Deck

Models: VT-MX4430A

Trade Name: HITACHI

This device complies with part 15 of FCC Rules. Operation is subject to the following two conditions:
(1)this device may not cause harmful interference, and (2)this device must accept any interference received, including interference that may cause undesired operation.

Responsible Party: Hitachi Home Electronics (America), Inc.
905 East South Street, Anaheim, CA 92805 U.S.A.
Tel: 714-780-0152